

		Transmitter/Sender																	
		ITK-200	ITKL-2	ITLS-16	ITGDT-809	ITS-150	ITZ-500	ITS-2000	ITS-23	YWT-8500	ITW-852	PIR-1000	PIR-5000	ITM-100	ITV-100	ITDS-50	SLT-7100	MLT-7100	
Receiver/Empfänger	CMR-1000	X				X	X			X			X	X	X				
	ITL-1000	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
	ITDL-1000	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X			
	ITL-3500	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X			
	ITL-230	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X			
	ITLM-1000	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X			
	ITWR-3500		X	X	X			X	X		X	X			X	X			
	CMR-1224	X				X	X			X				X	X	X			
	LBUR-100	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
	CMR-300	X				X	X			X					X				
	ITL-300	X	X	X	X	X	X	X	X	X	X				X				
	ITL-210	X	X	X	X	X	X	X	X	X	X				X				
	ITDM-250		X	X	X			X	X		X				X				
	ITL-250		X	X	X			X	X		X				X				
	CMR-500	X				X	X				X			X	X	X			
	ITL-500	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
	IT-1500		X	X	X			X	X		X	X			X	X			
	ITLR-3500	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
	ITLR-3500T	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
	ITLR-300	X	X	X	X	X	X	X	X	X	X	X			X				
	GRR-3500	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
	IT-2300	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
	ITR-7000	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		X	
	MLR-8300													X		X			X
	MLR-7100													X		X			X
	IT-9000		X	X	X			X	X		X	X			X				